



**INSTRUCTION MANUAL**

**Dual Hand-Held Wireless Mic System**

**OKLAHOMA SOUND CORP.**



**PACKAGE CONTENTS**

Your Unit should Contain the Following:


- Two Color Coded Microphones
- Two Coded Antennae
- Receiver Unit
- Cable

**SPECIFICATIONS**

Frequency Range.....Mic A: 57-59 MHz  
Mic B: 61-63 MHz

Operating Distance .....150-200 ft.

Power .....Receiver: 110V  
Transmitter Mics: 9V ea.



**FEATURES & ACCESSORIES**



- A) MICROPHONE "A" (w/GREEN BAND)
  - B) MICROPHONE "B" (w/RED BAND)
  - C) RECEIVER UNIT
  - D) ANTENNA LABELED "A"
  - E) ANTENNA LABELED "B"
- (CABLE and POWER CORD not shown)

REFER TO PICTURE AND LABELING OF PARTS FOR ASSISTANCE IN OPERATION

In event you experience problems with either MIC try to replace batteries with new fresh batteries. If problem persists feel free to call our customer service at 201-261-4111.

**TROUBLESHOOTING**

- A. Turn switch on microphones to the on position. Switch is located on underside of microphones. Turning on MIC A should illuminate green lamp on underside of microphone (next to switch). Turning on MIC B should illuminate red lamp on underside of unit (next to switch).
- B. When receiver is plugged into outlet power light on receiver unit should illuminate.
- C. When MIC A is in operation lamp labeled A on front of receiver should illuminate.
- D. When MIC B is in operation lamp labeled B on front of receiver unit should be illuminated.

**OPERATION**

Dual Hand-Held Wireless Mic System

OKLAHOMA SOUND CORPORATION

**ASSEMBLY**

Before you begin using the unit:

1. Remove microphone housing from MIC A and also from MIC B.
2. Insert 9 VOLT battery (not included) into battery chamber of both mic A and mic B. Make sure to connect the positive (+) and negative (-) prongs of battery as per diagram within chamber.
3. Plug one adapter of cable into jack labeled "AUDIO OUTPUT" — located on rear side of receiver unit and plug other adapter of cable into your existing sound system. Note: If your system does not have a 1/4" input, you must purchase an adapter.
4. Attach included 110V prong to power cord
5. Connect the antenna labeled "A" to upside of receiver unit on the left side and antenna labeled "B" to the upside of receiver unit on the right side.
6. Plug power cord into outlet.

www.oklahomasound.com • e-mail: info@oklahomasound.com

Tel 973-594-9000 • Fax 973-594-9339  
149 Entin Road, Clifton, NJ 07014  
**OKLAHOMA SOUND CORP.**

Congratulations! You are now the owner of the unique Dual Hand-Held Wireless Microphone System from Oklahoma Sound Corp.

The two wireless microphones can be used at the same time, karaoke-style or for speaker/audience participation. Just follow the instructions in this booklet and you are ready to go.

This state-of-the-art microphone system should provide trouble free usage for years to come. If you experience any difficulty with our product, or have questions, please call our customer service at (201) 261-4111.

**INTRODUCTION**

OKLAHOMA SOUND CORPORATION

Dual Hand-Held Wireless Mic System

**TABLE OF CONTENTS**

Introduction .....2

Package Contents & Specifications .....4

Product Features.....5

Assembly Instructions .....6

Operating Instructions ..... 7

Manufacturer's Warranty ..... 8